



5/8" Engineered UV Oil Cured CARE & MAINTENANCE

PREFINISHED ENGINEERED FLOORING MAINTENANCE INSTRUCTIONS FOR FLOORING PRODUCTS WITH CIRANOVA OIL FINISH.

It is **EXTREMELY IMPORTANT** that you read and understand this information completely prior to starting. Improper maintenance and/or care can void the warranty.

FLOOR PROTECTION:

Hardwood flooring can be a beautiful investment. To protect against moisture damage and abuse, follow the Tom Duffy Company's protection guidelines:

5/8" UV OIL CURED ENGINEERED FLOORS PROTECTION GUIDELINES

- Always clean the floor in accordance with the Ciranova cleaning & care product Instructions.
- Maintain indoor relative humidity between 40% and 65%. If this preventive measure is not kept, the flooring can crack, split, discolor, crook, bow and delaminate.
- Use felt leg protector pads, made for use with wood flooring, under all furniture legs.
- Wipe up spills immediately.
- Apply slip resistant runners or area rugs on high traffic areas.
- Use slip resistant door mats (outside and inside), to keep abrasives such as dirt, grit and sand off the floor.
- Replace narrow, hard (plastic) furniture rollers with wide rubber ones.
- Don't use rubber, foam back or plastic mats as they can discolor the floor.
- Don't use ammonia based cleaners, wax based products, detergents, bleach, polishes, oil soaps, or acidic materials like vinegar.
- Don't wear high heeled shoes when the metal post is unprotected and in direct contact with the wood flooring.
- Don't walk on the floor with any hard and/or sharp object protruding from the sole.
- Keep animal nails trimmed to prevent scratches to finish.

CLEANING & CARE SCHEDULE:

5/8" UV Oil Cured factory finished wood floor surfaces require periodic cleaning, care and oil treatments. The frequency of treatments depends on its use, the amount of foot traffic, general wear and tear, cleaning frequency, exposure to sunlight, etc.

Below is a guideline:

MONTHLY OR MORE OFTEN AS NEEDED:

Use Ciranova Flooring Soap. Mix 4 to 5 small caps into 10 liters of lukewarm water. Apply the cleaning solution on the wood by a floor cloth in the direction of the wood. Rinse the dirty floor cloth in clean water. Never clean afterwards with water, you may lose your protective layer. Allow to thoroughly dry before walking on the floor. Never use too much water on a wooden floor. Too much water will damage the floor.

ANNUALLY:

Use the Ciranova Maintenance Oil to ensure proper treatment of your wood floors. Apply a thin layer of Maintenance Oil Ciranova and let it impregnate the floor for a few minutes. Wipe off with a clean cloth. Polish the oil well dry to avoid sticking. Allow 12 hours to dry before any use of the floor, optimal hardness is reached after 48 hours. Don't use any water or maintenance products during this time. For application area use about 1 liter per 500 sf of already treated wooden flooring.